



		Spare part number	Spare part number
1	Air duct	691331	
2	Power cord		691345
3	Fuse		
4	Control module		
	<i>Serial Number range</i>		
	<i>Exxx#DWxxxxx</i>	691391	
	<i>Exxx#x#DW0026xxxx - Exxx#x#DW0042xxxx</i>		
	<i>Exxx#x#DW0043xxxx - Exxx#x#DW0065xxxx</i>	692821	
5	Condenser fan	692785	
6	Right upper hinge		692751
7	Left upper hinge		
8	Left bottom hinge		
9	Right bottom hinge		
10	Thermistor		691390
11	Thermistor cover		
12	LED panel	692753	
13	Technical panel	692754	
14	Circuit board light panel		692755
15	Control panel		
16	Control housing	692756	
16a	Display cover	692877	
17	Sticker	692757	
18	Drip tray		691740
19	Bracket		
20	Plate	691592	
21	Door latch plate		692758
22	Winter lock support		
23	Freezer door shell		691741
24	Freezer door shaft		
25	Freezer door upper hinge		
26	Freezer door torsion spring		
27	Freezer door bottom spring		
28	Clip shelf small	692759	
29	Shelf small	692760	
30	Clip shelf large	692761	
31	Shelf large	692762	
32	Food retainer	692763	
33	Door cover	692764	
34	Bottle retainer	692765	
35	Door bin	692766	
36	Vegetable bin	692767	

37	Lower hinge shaft		
38	Silicone blanking cap		692883
39	Upper hinge shaft		
40	Upper hinge shaft spring		
41	Panel retainer	692768	
42	Foaming door		692769
43	Door panel	69233027SP	
44	Handle groove		
45	Handle		
46	Handle connection shaft		692770
47	Big handle spring		
48	Small handle spring		

Note Identification Label

With a request for information or service, always provide the serial number of the refrigerator. The serial number is the code below the barcode on the identification label.

