








LE1328\_SOV70XXX

		Spare part number	Spare part number
1	Oven tap		
	<i>Production date: &lt; 14/03/2011 (E073M...)</i>	SSPA0452	
	<i>Production date: ≥ 14/03/2011 (E073M...)</i>	SSPA0451	
2	Grill tap		
	<i>Production date: &lt; 14/03/2011 (E073M...)</i>	SSPA0472	
	<i>Production date: ≥ 14/03/2011 (E073M...)</i>	SSPA0470	
	<i>Production date: ≥ 01/10/2022 (E274Z...)</i>	SSPA0474	
3	Control knobs	<i>Refer to page 3</i>	
4	Ignition switch	SSPA0381	
5	Light switch <b>*if fitted</b>	SSPA0591	
6	Bump Stops	SSPA0040	
7	Grill door	<i>Refer to page 4</i>	
8	Oven door	<i>Refer to page 4</i>	
9	Lower door	<i>Refer to page 4</i>	
10	Inner door glass	SSPA0253	
11	Oven seal	SSPA0062	
12	Oven shelf	SSPA0980	
13	Grill pan (full assembly including trivet and handle)	SSPA0993	
14	Oven lamp <b>*if fitted</b>	SSPA0560	
15	Oven burner		
	<i>Production date: &lt; 31-07-21 (E212Y...)</i>	SSPA0191	
	<i>Production date: ≥ 01-08-21 (E213Y...)</i>	SSPA0198	
16	Oven thermocouple (including electrode)		
	<i>Production date: &lt; 14/03/2011 (E073M...)</i>	SSPA0642	
	<i>Production date: ≥ 14/03/2011 (E073M...)</i>	SSPA0623	
17	Oven spark electrode (including part 21)	SSPA0321	
18	Spark generator	<i>Refer to page 3</i>	
19	Grill burner		
	<i>Production date: &lt; 13/04/2015 (E103S...)</i>	No longer available	
	<i>Production date: ≥ 13/04/2015 (E103S...)</i>	SSPA0185	
20	Grill thermocouple		
	<i>Production date: &lt; 29/10/07 (2007090212)</i>	SSPA0157	
	<i>Production date: &lt; 14/03/11 (E073M...)</i>	SSPA0643	
	<i>Production date: ≥ 14/03/11 (E073M...)</i>	SSPA0645	
21	Grill spark electrode (including part 17)	SSPA0321	

**Control knobs**


<b>Control knob sets</b>				
<b>Spare part number</b>	SSPA0920	SSPA0934	SSSPA1203	SSPA0916
<b>Colours available</b>	Black(.BK)	Chrome-Black(.CR/BK) Satin Black(.SA/BK)	Chrome(.CR)	Brushed Nickel(.BNK)
<b>Set quantity</b>	3	3	3	3

**Spark generators**


			
<b>Description</b>	2 terminals	4 terminals, 2 blanks	6 terminals
<b>Spare part number</b>	SSPA0302	SSPA0303	SSPA0399

## Cladding styles


No cladding



Side cladding



Behind handle cladding



## Grill doors

Spare part number	Glass	Print	Cladding	Cladding position	Handle style	Handle colour
SMAO3415.BK2X	Clear	Black	No	N/A		Stainless
SMAO3415.BK18X	Clear	Black	No	N/A		BNK
SMAO3415.BK23X	Clear	Black	No	N/A		BNK
SMAO3415.BKX/SVS5X	Clear	Black & Silver	No	N/A		BNK
SMAO3415.MIR1X	Mirror	N/A	No	N/A		Stainless
SMAO3415.SS3X	Clear	Silver	No	N/A		Black

## Drop Down oven doors

Spare part number	Glass	Print	Cladding	Cladding position	Handle style	Handle colour
SMAO3435.BK1X	Clear	Black	No	N/A		Stainless
SMAO3435.BK20X	Clear	Black	No	N/A		BNK
SMAO3435.BK23X	Clear	Black	No	N/A		BNK
SMAO3435.BKX/SVS5X	Clear	Black & Silver	No	N/A		BNK
SMAO3435.MIR1X	Mirror	N/A	No	N/A		Stainless
SMAO3435.SSX	Clear	Silver	No	N/A		Black

## Lower doors

Spare part number	Glass	Print	Cladding	Cladding position	Handle style	Handle colour
SMAO3450.BKX	Clear	Black	No	N/A	N/A	N/A
SMAO3450.BK/SVSX	Clear	Black & Silver	No	N/A	N/A	N/A
SMAO3450.MIRX	Mirror	N/A	No	N/A	N/A	N/A